

TR

BBU® SAFETY BC 200 DARBE EMİCİ ŞAPKA (BUMP CAP)

(EU) 2016/425 Yönergesi temel şartları ve EN 812:2012

KULLANIM

BU BİR ENDÜSTRİYEL GÜVENLİK KASK DEĞİLDİR

Bu darbe başlığı, EN 397 tarafından düzenlenen düşen nesnelerin veya hareketli askılı yüklerin etkisine karşı koruma sağlamaz. Bu başlık, sert ve hareketsiz nesnelere karşı küçük darbelerin enerjisini emmek için yapılmıştır. Bu darbe başlığı, düşen/fırlatılan nesnelerin veya hareketli askılı yüklerin etkisine karşı koruma sağlamaz ve EN 397 veya ANSI Z89'da belirtilen endüstriyel güvenlik kaskı yerine kullanılmamalıdır. Darbe başlığı, kısmi tahribat veya gövde hasarı ile bir darbenin enerjisini emmek için yapılmıştır. Bu tür bir hasar kolayca görünmese de, şiddetli darbeye maruz kalan herhangi bir darbe başlığı değiştirilmelidir. Yeterli koruma için, başlık kullanıcının başının boyutuna uymalı veya ayarlanmalıdır. Üretici tarafından önerilmediği sürece orijinal bileşen parçalarını değiştirmeyin veya çıkarmayın veya ek parçaları takmak amacıyla uyarlamayın. Üretici tarafından talimat verilmediği sürece boya, çözücü, yapıştırıcı veya kendinden yapışkanlı etiketler uygulamayın.

BUMP CAP'IN AYARLANMASI VE DENETLENMESİ

Bu şapka, tepesi öne ve arka arkaya gelecek şekilde takılmak üzere tasarlanmıştır. Uygun koruma için bu çarpma şapkası tepesi öne bakacak şekilde takılmalıdır. Şapkayı başın üstüne yerleştirin, böylece başın tepesine otursun ve tepesi kullanıcının görüşünü engellemeyecek şekilde geriye doğru eğin.

TEMİZLİK Aşındırıcı maddeler veya çözücüler kullanmayın. Kapağın herhangi bir bölümünü sabunlu suyla temizleyin ve yumuşak bir bezle kurulayın. Gerekirse, üreticinin talimatlarına göre hafif bir dezenfektan da kullanabilirsiniz.

ÜRÜN RAF/KULLANIM ÖMRÜ Optimum performansı sağlamak için tüm DARBE EMİCİ ŞAPKA bileşenlerinin kusursuz olması ve düzgün bir şekilde saklanması, bakımının yapılması ve temizlenmesi zorunludur. Darbe Emici Şapkaları 5 yıllık kullanımdan sonra değiştirmenizi öneririz. Darbe emici şapkanın kullanım ömrü Darbe, şok, UV radyasyonu ve uygunsuz kullanım gibi çeşitli faktörlere bağlı olacaktır. Optimum performansı sağlamak için darbe emici şapkaların tüm parçalarının düzgün bir şekilde saklanması, bakımının yapılması, temizlenmesi ve kusurlardan arındırılması esastır. Günlük kullanımda ve özellikle dış mekanlarda kullanıldığında, BBU® cap'in iki yıllık hizmetten sonra atılmasını önerir. Bazı aşırı durumlarda, bozulma daha da kısa bir sürede belirginleşebilir. İç mekanda veya ara sıra kullanım için 5 yıla kadar bir hizmet ömrü öngörüyoruz.

AKSESUARLAR VE YEDEK PARÇALAR Aksesuarlar ve/veya yedek parçalar (ter bandı, emniyet kemeri parçaları, çene kayışı, işitme koruması kabuğu vb.), mevcut olduğunda, BBU® SAFETY'den montaj talimatlarıyla birlikte teslim edilir. Yalnızca BBU® SAFETY tarafından sağlanan aksesuarları kullanın.

DEPOLAMA Şapkayı gereksiz yere güneş ışığına maruz bırakmaktan uzak, kuru yerlerde ve agresif maddelere karşı korumalı olarak saklayın. Depolama sıcaklığının (20 ± 15) °C aralığında tutulması önerilir. Optimum performansı sağlamak için, çarpma başlığının tüm parçalarının doğru şekilde depolanması, bakımının yapılması, temizlenmesi ve kusurlardan arındırılması önemlidir. Günlük kullanımda ve özellikle dış mekanlarda kullanıldığında, BBU® başlığın iki yıllık hizmetten sonra atılmasını önerir. Bazı aşırı durumlarda, bozulma daha kısa bir sürede bile belirgin olabilir. İç mekanda veya ara sıra kullanım için 5 yıla kadar bir hizmet ömrü öngörüyoruz.

UYARI: Boya ve çıkartmalar, zamanla Darbe emici şapkanın fiziksel özelliklerini değiştirebilecek malzemeler içerebilir. Bu ürünlerden herhangi birini uygulamadan önce, ABS ile uyumluluğunu doğrulayın.

ETİKETLEME Etiketler Darbe emici şapka üzerine silinmez bir şekilde işaretlenmiştir.

SORUMLULUK BBU® SAFETY, BBU® ürünlerinin uygunsuz kullanımından kaynaklanan doğrudan veya dolaylı, kazara veya kasıtlı hasarlardan kaynaklanan tüm sorumluluğu reddeder. Kullanıcı, BBU® SAFETY ürünlerinin uygunsuz kullanımından kaynaklanan tüm riskleri üstlenir.

İŞARETLERİN ANLAMI Üretici kimliği: BBU® SAFETY

Model: BC 200, Üretim kontrolü için bildirilen kuruluşun numarası: CE 0161, Avrupa Standardı Numarası: EN 812: 2012, Üretim yılı ve çeyreği: 20XX/OX, Boyut veya boyut aralığı: 53-63 cm

AB Uygunluk Beyanı : <http://bbusafety.com>

Onaylı Kuruluş : ASOCIACIÓN DE INVESTIGACIÓN DE LA INDUSTRIA TEXTIL (AITE). (NB 0161)

Central: Plaza Emilio Sala, 1. 03801 Alcoy / SPAIN

Üretici Firma : EGE IMBAT CORPORATION

: 1201/1 SOKAK NO:2/A YENİŞEHİR İZMİR / TURKEY

EN

BBU® SAFETY BC 200 BUMP CAP

Comply with the essential requirements of Directive (EU) 2016/425 & with the general requirements of the regulation EN 812:2012

USE

THIS IS NOT AN INDUSTRIAL SAFETY HELMET

This bump cap does not provide protection against the effect of falling objects or moving suspended loads regulated by EN 397. This cap is made to absorb the energy of small impacts against hard and immobile objects. This bump cap does not provide protection against effects of falling/thrown objects or moving suspended loads and should not be used instead of an industrial safety helmet as specified in EN 397 or ANSI Z89. Bump Cap is made to absorb energy of a blow by partial destruction or damage to shell. Though such damage may not be readily apparent, any bump cap subjected to severe impact should be replaced. For adequate protection, cap must fit or be adjusted to the size of user's head. Do not modify or remove original component parts or adapt for the purpose of fitting attachments unless recommended by the manufacturer. Do not apply paint, solvents, adhesives or self adhesive labels unless instructed by the manufacturer.

ADJUSTMENT AND INSPECTION OF THE BUMP CAP

The cap is designed to be worn with the peak forward and the adjustment backwards. For proper protection this bump cap must be worn with the peak facing forward. Place the cap on the head so that it sits down on to the top of the head, tilted back so that the peak does not obstruct the wearer's vision.

INSPECTION AND MAINTENANCE The cap will be checked daily before each use to check for cracks, breaks or damage. This bump cap's useful life is affected by many factors including: cold, heat, chemicals, sunlight and misuse. It should be examined daily for obvious signs of cracking, brittleness or damage. The production date is marked on the shell of each bump cap. Under normal circumstances this bump cap should offer adequate protection for 5 years. The shell should be cleaned/disinfected by wiping with a cloth moistened with a weak mild detergent solution and allowed to air dry. No strong or abrasive chemicals should be used. If the bump cap cannot be cleaned by this method it should be replaced. Follow instructions on the interior label for care of the fabric cover. When not in use the bump cap should be stored out of direct sunlight and not in contact with any chemicals or liquids. Care should be taken to avoid dropping the bump cap.

CLEANING Do not use abrasive materials or solvents. Clean any part of the cap with soapy water and dry with a soft cloth. If necessary, you can also use a mild disinfectant according to the manufacturer's instructions.

PRODUCT SHELF LIFE To ensure optimum performance it is imperative that all bumps caps components are free from defects and that they are properly stored, maintained and cleaned. We recommend replacing the bumps caps after 5 years of use. The lifespan of the cap will depend on several factors, such as shock, UV radiation and improper use. To ensure optimum performance it is essential that all parts of the bump cap are correctly stored, maintained, cleaned and free from defects. If in daily use and particularly when used outdoors, BBU® recommend the cap be discarded after two years in service. In some extreme circumstances, deterioration may be evident in an even shorter period of time. For indoor or occasional use, we would anticipate a service life up to 5 years.

ACCESSORIES AND SPARE PARTS The accessories and / or spare parts (sweatband, harness parts, chin strap, hearing protection shell etc.), when available, are delivered with installation instructions from BBU® SAFETY. Only use accessory provided by BBU® SAFETY.

STORAGE Keep the cap away from unnecessary exposure to sunlight, in dry places and protected against any aggressive agents. It is recommended that the storage temperature be kept in the range (20 ± 15) °C. To ensure optimum performance it is essential that all parts of the bump cap are correctly stored, maintained, cleaned and free from defects. If in daily use and particularly when used outdoors, BBU® recommend the cap be discarded after two years in service. In some extreme circumstances, deterioration may be evident in an even shorter period of time. For indoor or occasional use, we would anticipate a service life up to 5 years.

WARNING: Paint and stickers may contain materials that, with time, can alter the physical properties of the BUMP CAP. Before applying any of these products, verify their compatibility with ABS.

LABELLING: Labels are indelibly marked on the BUMP CAP.

RESPONSIBILITY: BBU® SAFETY declines all responsibility for any direct or indirect damage, accidental or deliberate, caused by improper use of BBU® products. The user assumes all risks arising from an improper use of BBU® SAFETY products.

MEANING OF THE MARKINGS: Manufacturer identification: BBU® SAFETY

Model: BC 200, Number of the notified body for production control: CE 0161, European Standard Number: EN 812: 2012, Year and quarter of manufacture: 20XX/OX, Size or size range: 53-63 cm

Declaration of Conformity : <http://bbusafety.com>

Notified Body : ASOCIACIÓN DE INVESTIGACIÓN DE LA INDUSTRIA TEXTIL (AITEX). (NB 0161)

Central: Plaza Emilio Sala, 1. 03801 Alcoy / SPAIN

Manufacturer : EGE IMBAT CORPORATION, 1201/1 SOKAK NO:2/A YENİŞEHİR İZMİR / TURKEY